



Recommended Tools for Installation

- Tape Measure
- Pencil
- Chalk Line
- Drill (Do **NOT** use impact drill)
- Laser/Level
- Sheet Rock Drywall Screws: Use 1-5/8" for single layer (Drywall screws not provided by Raco. Only framing assembly screws provided by Raco.)
- 1.5" Thin Putty Knife: For removing trim when needed
- 12" Block of Wood: To help not damage the product when installing
- Rubber Mallet/Dead Blow Hammer
- 5/32" Hammer Drill Bit
- 3/16" x 1-1/4" Concrete Anchors (Tapcon)
- 3/16" Drill Bit- For pre-drilling product
- #2 and #3 Phillips Bits
- Ladder
- Safety Glasses
- Miter Saw: Use Metal Blade 80 Teeth (*nonferrous*) or more for best results on cutting
- Small Pry Bar
- Cutting Snips
- Lineman's Pliers